



HOW TO ORDER




塑膠顏色編碼 (CAP COLOR)		
中文	ENGLISH	CODE
灰色	GRAY	G
綠色	GREEN	N
黑色	BLACK	K
紅色	RED	R
白色	WHITE	W
黃色	YELLOW	Y
透明	TRANSPARENT	T




PART NUMBER	KB-R01AC-PA-□
COLOR OF KNOB	G, K, N, R, T
SERIES	A.M.ML.PT.T



PART NUMBER	KB-R02AD-PA-□
COLOR OF KNOB	K
SERIES	A.M.ML.PT.T




PART NUMBER	KB-R02BD-PA-□
COLOR OF KNOB	K
SERIES	MS.PD




PART NUMBER	KB-R03BA-PA-□
COLOR OF KNOB	G, K, R
SERIES	MS.PD




PART NUMBER	KB-R03DA-PA-□
COLOR OF KNOB	G, K, R
SERIES	ACTUATOR (2 x 3 mm)













PART NUMBER	KB-R05AC-PC-□
COLOR OF KNOB	K, T
SERIES	A.M.ML.PT.T










PART NUMBER	KB-R06AD-PA-□
COLOR OF KNOB	G, K, W
SERIES	A.M.PT.T



PART NUMBER	KB-R08AC-K-PC-Y
COLOR OF KNOB	B.G.N.O.R.W.Y
SERIES	A.T.PT

 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R09FF-K-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G, K, W</td></tr> <tr> <td>SERIES</td><td>RS003</td></tr> </table> 	PART NUMBER	KB-R09FF-K-PA-□	COLOR OF KNOB	G, K, W	SERIES	RS003	 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R10CA-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>B, G, W, K, R</td></tr> <tr> <td>SERIES</td><td>KT</td></tr> </table> 	PART NUMBER	KB-R10CA-PA-□	COLOR OF KNOB	B, G, W, K, R	SERIES	KT
PART NUMBER	KB-R09FF-K-PA-□												
COLOR OF KNOB	G, K, W												
SERIES	RS003												
PART NUMBER	KB-R10CA-PA-□												
COLOR OF KNOB	B, G, W, K, R												
SERIES	KT												
 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R11AC-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>K, T</td></tr> <tr> <td>SERIES</td><td>A.M.P.T.T.ML</td></tr> </table> 	PART NUMBER	KB-R11AC-PA-□	COLOR OF KNOB	K, T	SERIES	A.M.P.T.T.ML	 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R12BD-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>K, T</td></tr> <tr> <td>SERIES</td><td>PD.MS</td></tr> </table> 	PART NUMBER	KB-R12BD-PA-□	COLOR OF KNOB	K, T	SERIES	PD.MS
PART NUMBER	KB-R11AC-PA-□												
COLOR OF KNOB	K, T												
SERIES	A.M.P.T.T.ML												
PART NUMBER	KB-R12BD-PA-□												
COLOR OF KNOB	K, T												
SERIES	PD.MS												
 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R13AC-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>K, T</td></tr> <tr> <td>SERIES</td><td>ML</td></tr> </table> 	PART NUMBER	KB-R13AC-PA-□	COLOR OF KNOB	K, T	SERIES	ML	 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R15AA-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>K, T, W</td></tr> <tr> <td>SERIES</td><td>A.M.P.T.T.ML</td></tr> </table> 	PART NUMBER	KB-R15AA-PA-□	COLOR OF KNOB	K, T, W	SERIES	A.M.P.T.T.ML
PART NUMBER	KB-R13AC-PA-□												
COLOR OF KNOB	K, T												
SERIES	ML												
PART NUMBER	KB-R15AA-PA-□												
COLOR OF KNOB	K, T, W												
SERIES	A.M.P.T.T.ML												
 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R16AH-W-PA-□-2P</td></tr> <tr> <td>COLOR OF KNOB</td><td>K, G</td></tr> <tr> <td>SERIES</td><td>RS003</td></tr> </table> 	PART NUMBER	KB-R16AH-W-PA-□-2P	COLOR OF KNOB	K, G	SERIES	RS003	 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R17FF-K-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>R, Y, N, B, W</td></tr> <tr> <td>SERIES</td><td>RS003</td></tr> </table> 	PART NUMBER	KB-R17FF-K-PA-□	COLOR OF KNOB	R, Y, N, B, W	SERIES	RS003
PART NUMBER	KB-R16AH-W-PA-□-2P												
COLOR OF KNOB	K, G												
SERIES	RS003												
PART NUMBER	KB-R17FF-K-PA-□												
COLOR OF KNOB	R, Y, N, B, W												
SERIES	RS003												
 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R18DA-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>R, Y, N, B, W</td></tr> <tr> <td>SERIES</td><td>ACTUATOR (2 x 3 mm)</td></tr> </table> 	PART NUMBER	KB-R18DA-PA-□	COLOR OF KNOB	R, Y, N, B, W	SERIES	ACTUATOR (2 x 3 mm)	 <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R18A1A-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>R, Y, N, B, W</td></tr> <tr> <td>SERIES</td><td>A.M.P.T.T.ML</td></tr> </table> 	PART NUMBER	KB-R18A1A-PA-□	COLOR OF KNOB	R, Y, N, B, W	SERIES	A.M.P.T.T.ML
PART NUMBER	KB-R18DA-PA-□												
COLOR OF KNOB	R, Y, N, B, W												
SERIES	ACTUATOR (2 x 3 mm)												
PART NUMBER	KB-R18A1A-PA-□												
COLOR OF KNOB	R, Y, N, B, W												
SERIES	A.M.P.T.T.ML												

  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R21BC-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>K , W</td></tr> <tr> <td>SERIES</td><td>MS.PD</td></tr> </table>	PART NUMBER	KB-R21BC-PA-□	COLOR OF KNOB	K , W	SERIES	MS.PD	  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-R22AC-PC-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K , W</td></tr> <tr> <td>SERIES</td><td>A.M.PT.T</td></tr> </table>	PART NUMBER	KB-R22AC-PC-□	COLOR OF KNOB	G , K , W	SERIES	A.M.PT.T
PART NUMBER	KB-R21BC-PA-□												
COLOR OF KNOB	K , W												
SERIES	MS.PD												
PART NUMBER	KB-R22AC-PC-□												
COLOR OF KNOB	G , K , W												
SERIES	A.M.PT.T												
  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S04BA-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>K , W</td></tr> <tr> <td>SERIES</td><td>MS.PD</td></tr> </table>	PART NUMBER	KB-S04BA-PA-□	COLOR OF KNOB	K , W	SERIES	MS.PD	  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S07AC-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K , W</td></tr> <tr> <td>SERIES</td><td>A.M.PT.T</td></tr> </table>	PART NUMBER	KB-S07AC-PA-□	COLOR OF KNOB	G , K , W	SERIES	A.M.PT.T
PART NUMBER	KB-S04BA-PA-□												
COLOR OF KNOB	K , W												
SERIES	MS.PD												
PART NUMBER	KB-S07AC-PA-□												
COLOR OF KNOB	G , K , W												
SERIES	A.M.PT.T												
  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S07BC-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K , W</td></tr> <tr> <td>SERIES</td><td>PD , MS</td></tr> </table>	PART NUMBER	KB-S07BC-PA-□	COLOR OF KNOB	G , K , W	SERIES	PD , MS	  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S14AC-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K</td></tr> <tr> <td>SERIES</td><td>A.M.PT.T</td></tr> </table>	PART NUMBER	KB-S14AC-PA-□	COLOR OF KNOB	G , K	SERIES	A.M.PT.T
PART NUMBER	KB-S07BC-PA-□												
COLOR OF KNOB	G , K , W												
SERIES	PD , MS												
PART NUMBER	KB-S14AC-PA-□												
COLOR OF KNOB	G , K												
SERIES	A.M.PT.T												
  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S19AC-PC-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K , W</td></tr> <tr> <td>SERIES</td><td>A.M.PT.T</td></tr> </table>	PART NUMBER	KB-S19AC-PC-□	COLOR OF KNOB	G , K , W	SERIES	A.M.PT.T	  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S20CD-PC-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K</td></tr> <tr> <td>SERIES</td><td>ACTUATOR (2.45 x 2.45mm)</td></tr> </table>	PART NUMBER	KB-S20CD-PC-□	COLOR OF KNOB	G , K	SERIES	ACTUATOR (2.45 x 2.45mm)
PART NUMBER	KB-S19AC-PC-□												
COLOR OF KNOB	G , K , W												
SERIES	A.M.PT.T												
PART NUMBER	KB-S20CD-PC-□												
COLOR OF KNOB	G , K												
SERIES	ACTUATOR (2.45 x 2.45mm)												
  <table border="1"> <tr> <td>PART NUMBER</td><td>KB-S23BD-PA-□</td></tr> <tr> <td>COLOR OF KNOB</td><td>G , K , W</td></tr> <tr> <td>SERIES</td><td>MS.PD</td></tr> </table>	PART NUMBER	KB-S23BD-PA-□	COLOR OF KNOB	G , K , W	SERIES	MS.PD							
PART NUMBER	KB-S23BD-PA-□												
COLOR OF KNOB	G , K , W												
SERIES	MS.PD												